





3rd Floor Channels


5501.HNN.NP.3W
 5501.HNE.NP.3W
 5501.HNN.NP.3E




Structural Reference
 Orientation: 0°

2nd Floor Channels

5501.HNN.NP.2A
 5501.HNE.NP.2A
 5501.HNZ.NP.2A
 5501.HNZ.NP.2W
 5501.HNZ.NP.2N
 5501.HNZ.NP.2E



Second Floor




Fourth Floor

4th Floor Channels


5501.HNN.NP.4W
 5501.HNE.NP.4W
 5501.HNN.NP.4E

5th Floor Channels

5501.HNN.NP.5W
5501.HNE.NP.5W
5501.HNN.NP.5E




Fifth Floor




Seventh Floor

6th Floor Channels

5501.HNN.NP.6W
5501.HNE.NP.6W
5501.HNN.NP.6E



Sixth Floor



Eighth Floor and Roof

7th Floor Channels

5501.HNN.NP.7W
5501.HNE.NP.7W
5501.HNN.NP.7E



Structural Reference
Orientation: 0°

8th Floor Channels

5501.HNN.NP.8W
5501.HNE.NP.8W
5501.HNN.NP.8E